



ITEM NO.	PART NO.	DESCRIPTION	QTY REQ'D	ITEM NO.	PART NO.	DESCRIPTION	QTY REQ'D
1	64913	Drive Cap	1	15	27131	Blade Hinge Screw	2
2	22693	Upper Housing	1	16	27847	Carbon Brush with shunt	2
3	21063	Insulator	1	17	64003	Blade Bracket	1
4	27198	Motor Frame Clip	1	18	64139	Blade Screw	2
5	21692	Screw	2	19	64027	Blade Guide	1
6	22591	Switch & Circuit Board Assy	1	20	S64013	Tension Spring	1
7	27184	Field Assembly	1	21	21977	Armature Assy (includes item 22)	1
8	64670	Brush Retaining Clip	1	22	21976	Cam & Bearing Assembly	1
9	64965	Insulator	1	23	21068	Large Bearing Cup	1
10	25061	Hanger Bail	1	24	65013	Front Motor Frame	1
11	64945	Rear Motor Frame	1	25	22319	Blade Drive Assembly	1
12	22656	Lower Housing (BGC2 UL)	1	26	15766	Blade Drive Screw	2
	22657	Lower Housing (BGC2 CSA)	1	27	22086	Rear Housing Screw	2
13	64606	Front Housing Screw	2	28	26049	Cord Set	1
14	S21743	Hinge Assembly (Model BGC & Oster 76 & 89 Blade Compatibility)	1	29	21067	Small Bearing Cup	1
	S27091	Hinge Assembly (Model BGC & Oster 10,22,111 Blade Compatibility)	1	30	64504	Brush Spring	1
				31	64991	Oil Seal	1
				32	17091	Self-Adhesive Foam Pad	1

IMPORTANT INFORMATION! When ordering repair parts, include part number, part name and model of clipper/trimmer. For best performance, clipper/trimmer blades should be CLEANED and OILED with Andis Clipper Oil before and after use. If repair is necessary, return to any Andis Authorized Repair Service Station, or to Andis Company, 1800 Renaissance Blvd., Sturtevant, Wisconsin, 53177 U. S. A. Pack carefully, mail either Insured Parcel Post, or U.P.S., attach a letter to outside of package explaining difficulty.