



| ITEM NO. | PART NO. | DESCRIPTION | QTY REQ'D |
|----------|----------|---------------------------------------|-----------|
| 1 | 64725 | Battery Pack | 1 |
| 2 | 64806 | Lower Housing | 1 |
| 3 | 64852 | Upper Housing | 1 |
| 4 | 64913 | Drive Cap | 1 |
| 5 | 64788 | Switch Button Retainer | 1 |
| 6 | 64902 | Switch Button | 1 |
| 7 | 64794 | Switch Button Lock | 1 |
| 8 | 64527 | Lock Ring | 1 |
| 9 | 64508 | Motor Battery Contacts | 2 |
| 10 | 64944 | Rear Motor Frame | 1 |
| 11 | 64943 | Front Motor Frame | 1 |
| 12 | 21067 | Small Bearing Mounting Ring | 1 |
| 13 | 64507 | Switch | 1 |
| 14 | 57993 | Screw | 2 |
| 15 | 64503 | Carbon Brush w/Shunt | 2 |
| 16 | 64504 | Brush Spring | 2 |
| 17 | 64670 | Brush Retainer Clip | 2 |

| ITEM NO. | PART NO. | DESCRIPTION | QTY REQ'D |
|----------|----------|---|-----------|
| 18 | 64514 | Motor Frame Clip | 2 |
| 19 | 64528 | Armature Assembly (Includes Item 20) | 1 |
| 20 | 27251 | Cam Assembly | 1 |
| 21 | 64529 | Magnetized Field Assembly | 1 |
| 22 | 15766 | Blade Drive Screw | 2 |
| 23 | 22319 | Blade Drive Assembly | 1 |
| 24 | 21068 | Large Bearing Mounting Ring | 1 |
| 25 | 64027 | Blade Guide | 1 |
| 26 | S64013 | Tension Spring | 1 |
| 27 | 64139 | Blade Screw | 2 |
| 28 | 64003 | Blade Bracket | 1 |
| 29 | 64533 | O-Ring | 1 |
| 30 | 64606 | Housing Screw | 4 |
| 31 | S21743 | Hinge Assy (Oster 76, 89 Blade Compatibility) | 1 |
| | S27091 | Hinge Assy (Oster 10, 22 & 111 Blade Comp.) | 1 |
| 32 | 27131 | Blade Hinge Screw | 2 |
| 33 | 64720 | Complete Charger (UL)(Remailer) | 1 |
| | 64803 | Complete Charger Assy (CSA) | 1 |

IMPORTANT INFORMATION! When ordering repair parts, include part number, part name and model of clipper/trimmer. For best performance, clipper blades should be CLEANED and OILED with Andis Clipper Oil before and after use. If repair is necessary, return to any Andis Authorized Repair Service Station, or to Andis Company, 1800 Renaissance Blvd., Sturtevant, Wisconsin, 53177 U. S. A. Pack carefully, mail either Insured Parcel Post, or U.P.S., attach a letter to outside of package explaining difficulty.